Homey wrote on Thu, 16 September 2010 16:331. Make sure on your 540 the matrix setting isn't on, that's the right button
2. Select 6CH, 6CH is 5.1, the .1 means the sub
3. Select the appropriate settings in the realtek manager.
1. Its not, iv tried with and without it
2.i dont have realtek, my pc has a VT2020 Audio Codec which works with something called envy HD manager or something like that, does not really show a man, and i tried with realtek but some reason, it never has a manager included with it, and way less settings