

---

Subject: Speaker issues

Posted by [Tupolev TU-95 Bear](#) on Sat, 21 Jan 2012 23:32:23 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

My speakers (4-6 years old) have been playing up recently, basically from time to time the music would go quiet as if I turned it down but then suddenly go back to the volume level I set it at. I've checked the wiring (these speakers needs to be hooked to a basscube as they are soundworks cambridge)and it appears ONE of the wirings loose (because these wirings has to be inserted to a red and blackhole) but because its protected by a plastic cover, is it recommended for me to snip the loose end and make another?

---